

# HELP FOR FROM TO

**PURPOSE:** The From To App is used to get the distance between two points. That's it, a quick, simple distance.

---

**When to Use** the From To App

**To get the distance between two points**

The From Point can be an Airport or a NAVAID or the current GPS location

The To Point can be an Airport or a NAVAID.

---

**How to Use** the From To App

Touch the From button to select the From point

Touch the To button to select the To point

Check the Use Current Loc switch to set the current GPS Location as the from Point

Check the Auto-Update switch to redraw the screen whenever the Current Loc changes

Select Nautical Miles or Kilometers as the distance unit of measurement.

Select the Map Type Normal, Satellite or Hybrid.

Back

# FROM TO

Current

Latitude: 38.938829

Longitude: -77.419355

Use Current Location

Auto Update

KOKV

Winchester Rgnl ARPT


Winchester, VA

Distance 36

NMiles  Kilometers

Map Type

Map  Satellite  Hybrid



Back

# FROM TO

**KJYO**

Leesburg Executive ARPT  
Leesburg, VA

Use Current Location  OFF

Auto Update  OFF

**KACK**


Nantucket Memorial ARPT  
Nantucket, MA

Distance 368

NMiles  Kilometers

Map Type

Map  Satellite  Hybrid



**KACK**  
Nantucket Memorial